



**Brown Davis Automotive Pty. Ltd.**

ABN: 72 657 573 544

*Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and  
Technical information the property of Brown Davis Automotive Pty. Ltd.*

**UGTP150T1**

**1**

Last edited: 3/10/2011

## **Underguard Part List and Installation Instructions**

*Underguard P/N: **UGTP150T1***

TOYOTA PRADO 150 SERIES  
TRANSMISSION GUARD

Item	Description	Quantity	Part number	P	C
	<b>**Requires front guard to fit UNTP150F1**</b>				
1	UNDERGUARD	1	UGTP150T1		
2	SET SCREW – HEX – M10 x 20mm – PLATED 8.8	3			
3	WASHER – PANEL PLATED – M10	3			
4	WASHER – SPRING PLATED – M10	3			
5	KIT LIST	1			
6	BROWN DAVIS AUTOMOTIVE STICKER	1			

Packed by (P): \_\_\_\_\_

Checked by (C): \_\_\_\_\_

Date Packed: \_\_\_\_ / \_\_\_\_ / \_\_\_\_

PH: +61 (3) 9762 8722 FAX: +61 (3) 9762 9829  
47 Holloway Drive, Bayswater, Victoria, Australia 3153

**info@browndavis.com.au    www.browndavis.com.au**



**Brown Davis Automotive Pty. Ltd.**

ABN: 72 657 573 544

*Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and Technical information the property of Brown Davis Automotive Pty. Ltd.*

---

## UGTP150T1

2

All Brown Davis Automotive Underguards are manufactured from 3.0 mm cold rolled steel, and electroplate finished to ensure maximum strength and durability and minimum corrosion susceptibility. This gauge of steel is sufficiently impact resistant.

All Underguards are M.I.G. (Metal Inert Gas) welded to assure the strongest possible seams and are strengthened where necessary to add further protection and impact capabilities. Where needed guard bolt holes/bolt heads are protected with strategically placed steel shields.

In all cases, Brown Davis Underguards are designed with severe off road use in mind and are designed to protect against impact and damage sustained due to harsh conditions or coming into contact with terrain.

### Installation Instructions

1. Undo both gearbox cross-member support brackets leaving one bolt in on each side, and move them out of the way (as shown below)



2. Use lifting device to lift Brown Davis guard into place
3. fit 3x M10 x 20mm bolts to front of (UGTP150T1) keep loose



4. Refit gearbox cross-member supports using standard bolts (as shown below)



5. tighten all bolts