



Brown Davis Automotive Pty. Ltd.

ABN: 72 657 573 544

*Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and
Technical information the property of Brown Davis Automotive Pty. Ltd.*

UGVWAT1

1

Last edited: 4/10/2011

Underguard Part List and Installation Instructions

*Underguard P/N: **UGVWAT1***

VALSWAGON AMAROK
TRANSMISSION, TRANSFER CASE

Item	Description	Quantity	Part number	P	C
1	UNDERGUARD	1	UGVWAT1		
6	WASHER – PANEL PLATED – M8	2			
9	KIT LIST	1			
10	BROWN DAVIS AUTOMOTIVE STICKER	1			

Packed by (P): _____

Checked by (C): _____

Date Packed: ____ / ____ / ____

PH: +61 (3) 9762 8722 FAX: +61 (3) 9762 9829
47 Holloway Drive, Bayswater, Victoria, Australia 3153

info@browndavis.com.au www.browndavis.com.au



Brown Davis Automotive Pty. Ltd.

ABN: 72 657 573 544

Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and Technical information the property of Brown Davis Automotive Pty. Ltd.

UGWVAT1

2

All Brown Davis Automotive Underguards are manufactured from 3.0 mm cold rolled steel, and electroplate finished to ensure maximum strength and durability and minimum corrosion susceptibility. This gauge of steel is sufficiently impact resistant.

All Underguards are M.I.G. (Metal Inert Gas) welded to assure the strongest possible seams and are strengthened where necessary to add further protection and impact capabilities. Where needed guard bolt holes/bolt heads are protected with strategically placed steel shields.

In all cases, Brown Davis Underguards are designed with severe off road use in mind and are designed to protect against impact and damage sustained due to harsh conditions or coming into contact with terrain.

Installation Instructions

1. Remove the 2 M10 bolts at the rear of the standard transmission guard



2. Remove 4 M8 bolts from rear of the front standard sump guard



3. Slide Brown Davis guard in to place



4. Fit supplied M10 washers to rear M10 bolts and loosely fit bolts
5. Refit the 4 standard M8 bolts to front of Brown Davis guard
6. Tighten all bolts





Brown Davis Automotive Pty. Ltd.

ABN: 72 657 573 544

Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and Technical information the property of Brown Davis Automotive Pty. Ltd.

UGWVAT1

4

