



Brown Davis Automotive Pty. Ltd.

ABN: 72 657 573 544

Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and Technical information the property of Brown Davis Automotive Pty. Ltd.

UGTP150T2

1

Underguard Part List and Installation Instructions

*Underguard P/N: **UGTP150T2***

TOYOTA PRADO 150 SERIES
TRANSFER CASE GUARD

Item	Description	Quantity	Part number	P	C
1	UNDERGUARD	1	UGTP150T1		
2	SET SCREW – HEX – M10 x 20mm – PLATED 8.8	4			
3	SET SCREW – HEX – M10 x 55mm – PLATED 8.8	2			
4	WASHER – PANEL PLATED – M10	4			
5	WASHER – FLAT PLATED – M10	4			
6	WASHER – SPRING PLATED – M10	6			
7	NUT – PLATED – M10	2			
8	GUARD BRACKET	2	UG-GB-TP150T2		
9	KIT LIST	1			
10	BROWN DAVIS AUTOMOTIVE STICKER	1			

Packed by (P): _____

Checked by (C): _____

Date Packed: ____ / ____ / ____



Brown Davis Automotive Pty. Ltd.

ABN: 72 657 573 544

Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and Technical information the property of Brown Davis Automotive Pty. Ltd.

UGTP150T2

2

All Brown Davis Automotive Underguards are manufactured from 3.0 mm cold rolled steel, and electroplate finished to ensure maximum strength and durability and minimum corrosion susceptibility. This gauge of steel is sufficiently impact resistant.

All Underguards are M.I.G. (Metal Inert Gas) welded to assure the strongest possible seams and are strengthened where necessary to add further protection and impact capabilities. Where needed guard bolt holes/bolt heads are protected with strategically placed steel shields.


In all cases, Brown Davis Underguards are designed with severe off road use in mind and are designed to protect against impact and damage sustained due to harsh conditions or coming into contact with terrain.

Installation Instructions

1. Remove standard stone tray from bottom of transfer case and retain standard bolts.



2. Fit the 2x guard brackets to the transfer case using standard bolts (as shown blow) and tighten.



3. Using lifting device to Lift guard into place.
4. Fit 4x supplied M10 × 20mm bolts with spring and flat washers into guard mounting bracket keep loose.



5. Fit supplied M10 × 55mm bolts to gear box mount using flat and spring washers (as shown below)



6. Tighten all bolts.